

# Can you look at a surface and say that it's clean?

Take the guesswork out of your cleaning program with **SANI-SHIELD®** and the **System Sure®** Luminometer!

ATP or adenosine triphosphate is the energy transfer molecule found in all living cells.

Measure the amount of ATP on the surface and you can determine the surface fouling index.

The higher the reading, the higher the potential for contamination. Gain a foothold on your surfaces and decrease the level of soiling with SANI-SHIELD & SANI-SCRUB.



Part # 10001



Part # 53001

Part # 40102

Use SANI-SHIELD® and SANI-SCRUB® and prove their effectiveness with the System Sure® Luminometer

- Be pro-active not re-active
- Reduce costs with less downtime, less maintenance and less chemicals
- Pinpoint soil & odor-causing bacteria, mold & mildew hotspots
- Predict potential contamination problems
- Eliminate pre-cleaning, dwell times & post-cleaning
- Be in control of surface hygiene!

#### HYGIENE SCALE:

0-30	Food Contact Safe
30-100	Considered Clean
100-200	Caution
200 +	Unclean

Contact your SANI-SHIELD® Representative to hear more about the SANI-SHIELD® Protection Plan!